

**SUPPLY VOLTAGE**

VAC	VDC	
Phase (L)	+ VDC	1
Neutral (N)	- VDC	2
Earth (PE)	Earth (PE)	3

(See 4.1 Technical features)

**OUTPUT SIGNALS**

CUMULATIVE ALARM RELAY (K1)


OUTPUT VOLTAGE FOR ELECTRO-VALVES  
(For output voltages see 4.1 Technical features)

**WITH OUTPUT VDC THE COMMON IS CONNECTED TO + VDC**  
**WITH SUPPLY VOLTAGE VDC THE MINUS IS CONNECTED TO EARTH**  
**\*\* DO NOT CONNECT TO EARTH (3) THE COMMON OF THE EV. (30)**

**INPUT SIGNALS**

ADDITIONAL CYCLES FROM FAN CONTACT  
Contact close = FAN on  
LINK CLAMPS IF NOT USED WITH INPUTS  
FROM EXTERNAL CONTACT ENABLED  
(See 2.2 Code D1a)

ON / OFF CLEANING FROM EXTERNAL CONTACT  
Contact close = cycle enabled  
LINK CLAMPS IF NOT USED WITH INPUTS  
FROM EXTERNAL CONTACT ENABLED  
(See 2.2 Code C6/D6)



\* ON REQUEST